



















LAZ16 Push Button Series

Push button	Description	Contact	Circuit	Color	Type	Contour
	Indicator Buzzer 12/24V AC/DC			● Black ● Black ● Black	LAZ 16-MFA LAZ 16-MFF LAZ 16-MFCF	
LAZ 16-MFF						
	Installed light Mushroom button LED 24V/AC/DC Neon 200V/AC	1NO+1NC 2NO+2NC		● Red ● Green/PG ● Yellow ● White/PW ● Pure Blue	LAZ 16-11MD LAZ 16-11MDL LAZ 16-22MD LAZ 16-22MDL	
LAZ 16-11MD						
	Mushroom button	1NO+1NC 2NO+2NC		● Red ● Green ● Yellow ● White ● Blue	LAZ 16-11M LAZ 16-11ML LAZ 16-22M LAZ 16-22ML	
LAZ 16-11M						
	Mushroom Emergency push button turn to release	1NO+1NC 2NO+2NC		● Red ● Green ● Yellow ● White ● Blue	LAZ 16-11ZS LAZ 16-22ZS	
LAZ 16-22ZS						
	Selector switch with lamp LED 24V/AC/DC Neon 220V/AC	NO+NC 2NO+2NC		● Red ● Green ● Yellow ● White ● Blue	LAZ 16-11×AD-2P LAZ 16-11×AD-3P LAZ 16-22×AD-2P LAZ 16-22×AD-3P	
LAZ 16-11×AD						
	Selector switch with lamp LED 24V/AC/DC Neon 220V/AC	NO+NC 2NO+2NC		● Red ● Green ● Yellow ● White ● Blue	LAZ 16-11×FD-2P LAZ 16-11×FD-3P LAZ 16-22×FD-2P LAZ 16-22×FD-3P	
LAZ 16-11×FD						