

XB2 Pilot Light & Pushbutton



ZB2BE101



ZB2BE102



XB2-EA51



XB2-EA42



XB2-EA35



XB2-EU21



XB2-EP42



XB2-EA4322



XB2-EL3311



XB2-EL3341



XB2-EC42



XB2-EL9325

Description	Contact Type	Supply voltage	Color	Reference
	N/O	250V	Green	ZB2BE101
	N/C	50/60Hz	Red	ZB2BE102
Even button spring return			White	XB2-EA11
			White	XB2-EA21
	N/O		Green	XB2-EA31
			Yellow	XB2-EA51
			Blue	XB2-EA61
Even button spring return	N/C		Red	XB2-EA42
Even button spring return			White	XB2-EA15
			Black	XB2-EA25
	N/O+N/C		Green	XB2-EA35
			Yellow	XB2-EA55
			Blue	XB2-EA65
			Red	XB2-EA45
With protection spring return	N/O		Black	XB2-EU21
			Green	XB2-EU31
			Yellow	XB2-EU51
			Blue	XB2-EU61
With protection spring return	N/C		Red	XB2-EU42
Even button (Atansparent silica gel cover) unmarked Ip65	N/O		White	XB2-EP11
			Black	XB2-EP21
			Green	XB2-EP31
			Yellow	XB2-EP51
			Blue	XB2-EP61
	N/C		Red	XB2-EP42
			Green	BX2-EA3311
			Green	BX2-EA3361
	N/O		White	BX2-EA3341
			Black	BX2-EA3351
	N/C		Red	BX2-EA3322
			Red	BX2-EA3342
	N/O		Green	BX2-EA3331
			Black	BX2-EA3321
			Black	BX2-EL21
	N/O		Green	BX2-EL31
			Yellow	BX2-EL51
			Blue	BX2-EL61
	N/C		Red	BX2-EL42
			Green	BX2-EL3311
	N/O		Green	BX2-EL3361
			Black	BX2-EL3351
	N/O		White	BX2-EL3341
	N/C		Red	BX2-EL4322
			Red	BX2-EL4342
			Black	BX2-EC21
	N/O		Green	BX2-EC31
			Red	BX2-EC42
	N/C		Red	BX2-EC42
	N/O+N/C		GreenRed	BX2-EL9325
			GreenRed	BX2-EL9425