

XB2 Pilot Light & Pushbutton



XB2-ER42



XB2-ES542



XB2-ET42



XB2-ES142



XB2-ED21



XB2-ED33



XB2-EJ21



XB2-EJ33



XB2-EG33



XB2-EW3361



XB2-EW8465

Description	Contact Type	Supply voltage	Color	Reference
Mushroom head	N/O	250V 50/60Hz	Black	XB2-ER21
			Green	XB2-ER31
	N/C		Red	XB2-ER42
Turn to release	N/C		Red	XB2-ES442
			Red	XB2-ES542
			Red	XB2-ES642
Push-pull Red	N/C		Red	XB2-ET42
			Red	XB2-EX42
Turn to release Red release (Key n°445)	N/C		Red	XB2-ES742
			Red	XB2-ES142
			Red	XB2-ES242
2 position				XB2ED21
			N/O+N/C	XB2ED25
			N/O	XB2ED41
			N/O+N/C	XB2ED45
3 position				XB2ED33
				XB2ED53
				XB2ED73
				XB2ED83
2 position			N/O	XB2EJ21
			N/O+N/C	XB2EJ25
			N/O	XB2EJ41
			N/O+N/C	XB2EJ45
3 position				XB2EJ33
				XB2EJ53
				XB2EJ73
				XB2EJ83
2 position			N/O	XB2EG21
			N/O+N/C	XB2EG25
			N/O	XB2EG41
			N/O+N/C	XB2EG45
			N/O	XB2EG61
			N/O+N/C	XB2EG65
3 position				XB2EG33
				XB2EG53
				XB2EG03
				XB2EG73
Direct bulb supplied	N/O		White	XB2-EW3161
			Green	XB2-EW3361
			Yellow	XB2-EW3561
			Blue	XB2-EW3661
			Red	XB2-EW3462
Via integral resistor Ba9s, LED24V bulb supplied	N/O		White	XB2-EW3171
			Green	XB2-EW3371
			Yellow	XB2-EW3571
			Blue	XB2-EW3671
			Red	XB2-EW3472
	N/C			