

	RJ1-A100A5		<p>3 — 4</p> <p>1 — 2</p>	
	RJ1-A100S2		<p>1 — 2</p>	
	RJ1-A100XT		<p></p> <p></p>	
	RJ1-A200A3		<p>3 — 4</p> <p>3 — 4</p>	
	RJ1-A200A5		<p>3 — 4</p> <p>1 — 2</p>	
	RJ1-A300A		<p>3 — 4</p> <p>1 — 2</p> <p>3 — 4</p>	

	<p>蜂鸣器 AC/DC 12 - 24V</p> <p>1 Green led lights</p> <p>1 Red led lights</p>	<p></p> <p></p> <p>AC/DC 24V</p> <p></p> <p>AC/DC 24V</p>	RJ1-A300V	
	<p>LED 灯 AC/DC 12 - 24V with:</p> <p>1 Green led lights</p> <p>1 Red led lights</p>	<p></p> <p></p>	RJ1-A200V	
	<p>紧急停止 Ø30 twist to release</p> <p>1 Up push button 2NO </p> <p>1 Down push button 2NO </p> <p>1 Rotary switch with key 0 - 1 - 90° switching 1NO</p>	<p></p> <p></p> <p></p> <p></p>	RJ1-A400 SAAZ	
	<p>紧急停止 Ø40 twist to release</p> <p>1 Up push button - 1NO - 1NC </p> <p>1 Down push button - 1NO - 1NC </p> <p>1 Start push button - 1NO - 1NC </p>	<p></p> <p></p> <p></p> <p></p>	RJ1-A400 SAAA	
	<p>紧急停止 Ø40 twist to release with sectors:</p> <p>1 Up push button - 1NO - 1NC </p> <p>1 Down push button - 1NO - 1NC </p> <p>1 Start push button - 1NO - 1NC </p> <p>1 Cam switches 1-0-2 90° switching - 1NO + 1NC</p>	<p></p> <p></p> <p></p> <p></p> <p></p>	RJ1-A500 SAAAZ	