


























## LAY5 Control Switch Box Series 按钮开关

Control switch	Description	Contact	Symbol	Type	Contour
 <p>LAY5-EPBS2</p>	2 holes control box 1 white spring return button 1 red emergency button turn to release Ip54	NC+1N/O			LAY5-EPBS2
		NC+2N/O			LAY5-EPBS22
 <p>LAY5-EPBS3</p>	3 holes control box 1 white spring return button 1 black spring return button 1 red emergency button turn to release Ip54	NC+2N/O			LAY5-EPBS3
		NC+2N/O+2N/O			LAY5-EPBS32
 <p>LAY5-EPBS4</p>	4 holes control box 1 balck spring return button 1 white spring return button 1 balck spring return button 1 red emergency button turn to release Ip54	NC+3N/O			LAY5-EPBS4
		NC+3N/O+3N/O			LAY5-EPBS42
 <p>LAY5-EPBS5</p>	5 holes control box 1 balck spring return button 1 white spring return button 1 balck spring return button 1 white spring return button 1 red emergency button turn to release Ip54	NC+4N/O			LAY5-EPBS5
		NC+4N/O+4N/O			LAY5-EPBS52
 <p>LAY5-EPBS6</p>	6 holes control box 1 white spring return button 1 balck spring return button 1 white spring return button 1 balck spring return button 1 white spring return button 1 red emergency button turn to release Ip54	NC+5N/O			LAY5-EPBS6
		NC+5N/O+5N/O			LAY5-EPBS62